



MERIDIAN

HD621

HDMI Audio Processor

RS232 Control Information

The RS232 interface for the HD621 can be operated from any terminal which operates at 9600 baud with 1 start bit, 1 stop bit and no parity. Commands take the form of 2 ASCII characters, in some cases followed by a signed argument ('nn' below). All characters are echoed by the processor. A carriage return character will execute the command, and backspace is also implemented.

The following table lists the commands available. The HD621 accepts source selection and standby commands only.

Source Commands.

CD Selects CD source.
RD Selects Radio.
DV Selects DVD.
AX Selects Aux.
DC Selects Disc.
TA Selects Tape.
TV Selects TV. 5
CB Selects Cable.
SA Selects Satellite.
V1 Selects VCR1.
V2 Selects VCR2.
GA Selects Game.

General Commands.

SB Standby.